
## **Space Management**

PostalCAD Work Instructions

27 July 2017



Start a new drawing (NEW) based on *PostalCAD* Space Management template. Follow instructions to **attach** (MX) and color key external references.

Pick the \*Set Layer (SB) option and choose a standard *PostalCAD* space layer. Workroom floor operations and staging are placed on the FACPLAN-BOUNDARY layer (created when "Workroom" is selected).

3 Use the **RECTANGLE (REC)** and **PLINE (PL)** commands to create closed boundaries, tracing workroom and support spaces from underlying external references.


Use the **HIGHLIGHT SPACE** (HS) utility to hatch spaces with transparent fill.

Break large, complex spaces like aisle ways and corridors into multiple, smaller areas.

Use the \*SPLIT (SSP) command to subdivide spaces and the \*MERGE (MPS) command to combine them.

Postal Regulatory Commission Submitted 1/29/2020 2:37:06 PM

PostalCAD Space Management of customers to track and analyze space allacations within 2012 processing facilities and retail & delivery units.



## **Space Management**

PostalCAD Work Instructions


27 July 2017

Use SET ARCHITECTRUAL SCALE (SAS) utility to control size of space text.

Use the \*TAG SPACE (TS) feature to identify spaces and display area in square feet. Selecting a workroom floor space will cause the Select MODS dialogue to appear.



Selecting any other type of space will initiate a sequence of prompts at the command line for user input. This input is broken into two parts: 1) room number and 2) description. For each of these parts you have the option to pick text or attributes from the underlying external references to supply key information.



If no underlying text is available then hit **Enter** and type the information in

the edit box.



Use the **READ ROOM TAG (RRT)** command to automatically read underlying room tag data to label support spaces.

In the \*TAG SPACE (TS) utility, use the "Bigger/Smaller/Rotate/ **Move**" options to change the size, and placement of tags.

Use the "Sequential" option to create unique tags with indexed suffix and the "Staging" option to tag staging space associated with a mail processing operation.








Use the \*SCALE TAG (SST) utility to change the size of one or more labels after spaces have been tagged.

## **Space Management**


PostalCAD Work Instructions

27 July 2017

Use the \*ZOOM TO (ZS) utility to automatically zoom to a specific space.



1 3 Use the \*REPORT (SMR) utility to create a Space Management Report based on selected areas.



| FACPLAN-BOUNDARY   |   |  |  |
|--|---|--|--|
| ID   | Description   | Area   | Perimeter  |
| 010<br>134<br>141_01<br>141_02<br>141_03<br>141_04<br>141_05<br>141_STG_01 | MAIL PREPARATION SPSS AFSM 100 AFSM 100-ATHS/AI | 33,324<br>15,277<br>6,680<br>7,181<br>6,607<br>5,961<br>6,005<br>5,266 | 802<br>825<br>402<br>401<br>394<br>385<br>386<br>587 |